



PROFESSIONAL POLE DANCE EQUIPMENT

www.gympole.com



GP BASE CARTUsage guide


Cart for handling the Flying GP base.

ATTENTION

MAINTENANCE

If you need to move the base, do not slide it as this may damage it. Always lift it up and only then carry it, or use the cart.


Avoid cleaning the cart with cleaning agents that may damage the powder coated surface finish.



MOUNTING THE BASE


step 01

Fold the cart over the base and slide it over the upper edge of the base.



step 02

Slide the moving part on the other side into position 1. Ensure it covers the base snugly.




MOUNTING THE BASE


step 03

Check if the safety lock is in position 1. Check if the base is firmly in place.

step 04

You may now lift the cart and go.






UNMOUNTING THE BASE


step 01

To unmount the base, first set it down at your desired location and then lay the cart with the base on the floor.



step 02

Release the safety lock and pull out the moving part from position 1.



UNMOUNTING THE BASE

step 03

Pull out the second part from under the base while sliding the whole cart in the opposite direction.

step 04

You may now put the cart aside.

